

# PINTAIL INSTRUCTIONS

For instructional video and additional products go to

[www.wonderduck.com](http://www.wonderduck.com)

---

All Wonderduck Decoys come with a Limited & Extended Warranty and Repair Guarantee! Even if you **SHOOT IT**, Maximum repairs are only \$35.00 for 2013; however your repair fee could be less than \$35.00 depending on condition of decoy. **\*\*DO NOT RETURN DECOY TO DEALER FOR REPAIRS!\*\*** For repairs please call Wonderduck Decoys at **1-800-876-1697** or ship repair decoy to (along with your name, return shipping address & telephone #: **Wonderduck Decoys** or visit [www.wonderduck.com](http://www.wonderduck.com)

**505 N. Price St.  
Marshall, TX 75670**

## **INSTRUCTION:**

All Wonderduck's run on either 1 or 2 D cell batteries. To locate battery holder, decoy head, and attachments you must first open the decoy. Under the decoy; find the green wire on the base of the black float. One side of the green wire is looped inside the decoy shell to act as a hinge. The other side will have the green wire poking through a hole in the shell. Gently press your thumb or finger inside the cut of the black float directly under the wire and the hole. Push the wire completely through the hole and open the decoy like a book. All attachments fasten on to the **FLAT** side of the motor shaft with a Phillips head screw. Slide the attachment as far as possible onto the motor shaft and tighten the screw on to the **FLAT** side of the motor shaft. Failing to attach Wing & Foot attachments near the base of the motor shaft will cause excess vibration and additional wear & tear on the motors. **DO NOT RUN ATTACHMENTS ON THE TIP OF THE MOTOR SHAFT!**

Attachments included with your decoy: Black Weedless Adjustable Paddling Feet

## **Weedless Adjustable & Interchangeable Paddling Feet**

Wonderduck's **New Weedless Paddling Feet** for 2013 are 60% lighter, adjustable, quickly replaceable, and come in a variety of colors. Our new feet & attachments are designed to reduce motor vibration while increasing battery life and water motion. Wonderduck's New Paddling Feet are 1" wide & 3" inches long and create the illusion of small rotating wings. The feet are designed to add a flash of color similar to a ducks wing patch and are available in 10 different colors; giving you Water Motion, Decoy Motion and Sight Motion in COLOR all at the same time. The flash of color looks completely natural to a duck & may be the difference on getting them to your spread. Unlike rotating wings-our weedless/adjustable paddling feet-**WILL NOT FLARE DUCKS CLOSE IN!!!** If you believe they are creating too much Sight Motion, you can change to Black or Clear paddling feet. Black & Clear Feet provide Water & Decoy Motion without the flash of color. The decoy's swimming motion can be manipulated by adjusting Wonderduck's Paddling Feet inward or outward & by positioning the decoy's head to the left, right, or straight ahead. To purchase Wonderduck's weedless adjustable paddling feet please call 1-800-876-1697 or visit [www.wonderduck.com](http://www.wonderduck.com).

Pintail Instructions